



www.opmustang.com

Tremec Instruction

Please read, understand the supplied instructions and reference these instructions and perform service with the vehicle on a level secure surface. **If you have factory installed oil coolers read that section before starting.**



Transmission Drain Plug Location. Use a 3/8" Drive Extension to remove.

Once fluid is completely drained, inspect and clean the drain plug. Apply supplied sealing tape to drain plug and reinstall to 21ft/lbs. or using firm pressure. **Do not over tighten!**

Fill Plug on Drivers Side of Transmission. Use a 3/8" Drive Ratchet to remove.



Assemble pump on to the first bottle and feed hose into the fill plug hole. It is difficult due to available clearance but make sure the hose is securely in the fill hose. Proceed to pump oil into transmission until oil just begins to come out and fill hole. Clean and inspect fill plug and apply supplied sealant tape and install to 21ft/lbs. or with firm pressure. **Do not over tighten!**

Procedure for Vehicles Equipped With Factory Oil Coolers

After filling transmission as described, install a cleaned fill plug **without** sealant tape loosely in the fill hole.

Start vehicle and run for 2 minutes with the clutch engaged (clutch pedal released) in neutral to allow the transmission fluid to circulate through

transmission fluid cooling system or the transmission will be under-filled.

After two minutes, shut off the vehicle, remove the fill plug and top off. Install sealing tape to clean plug and install to 21ft/lbs. or with firm pressure. **Do not over tighten.**

Thank you for the continued support!